

## BARNIER<sup>®</sup> 9080B

### 30 days U.V Resistant 80°C Paper Masking Adhesive

#### DESCRIPTION

Scapa 9080B is a 0.13mm semi crepe tape coated with an acrylic adhesive system resistant to ultraviolet rays for inside and outside usage. Scapa 9080B is a 30 days application and resists up to 80°C

#### APPLICATIONS

- Long-lasting masking

#### PRODUCT BENEFITS

- U.V. resistant (up to 30 days)
- Suitable for brush and spray painting
- suitable for protecting a wide variety of surfaces such as steel, aluminum, wood or glass
- Indoors and outdoors up to 80 °C (60 minutes)

#### TECHNICAL PROPERTIES

Technical Property	Nominal Value	Unit	Test Method
Adhesion to Steel	1.4	N/cm	AFERA 5001
Elongation at Break	11	%	AFERA 5004
Tensile Strength	29	N/cm	AFERA 5004
Total Thickness	135	µm	AFERA 5006

Note:

\*\*\*This will be taken from the core product for the SAP Material Group\*\*\*

## STANDARD PRESENTATIONS

- Colours: Blue
- Core: 76 mm Scapa branded cardboard core
- Packaging: Various packaging available
- Roll Length: 50m
- Roll Width: 25; 38; 50; 110 mm

*Note:*

## RECOMMENDATIONS

The rolls should be stored flat on their cut edges in the original packaging. The product must be protected from dust, heat, moisture, direct sunlight and solvent fumes. Storage temperature between +10°C and +30°C. Under these conditions, the storage life of the tape in a temperate climate should not exceed 6 months. Surfaces should be clean, dry and free of dust, grease, oil or other contaminants.

Scapa masking tapes are not suitable for outdoor exposure and should not be submitted to prolonged periods of sunlight, as tapes may become difficult to remove. Clean removal may also vary with surface type, lacquers, primers and paints nature as well as the temperature of the surface at removal. For best results, remove the tape as soon as possible after applying the paints pulling it slowly at a 45° angle with constant speed. Because of the diversity of substrates used by the end user, the test conducted by the end user himself is the safest way to test the substrates before the final application